

HAB000K (2010年4月～モデル) のサポートOS - 一覧表

Table showing OS support for HAB000K. Columns include processor types (4-core RS440, 2-core RS220, TS20) and various RAID configurations (e.g., 2.5" SAS2.0 RAID5, 3.5" SATA2 RAID5). Rows list supported OS versions like Windows Server 2003, Windows Server 2008, and VMware ESXi.

Table showing OS support for HAB000-es. Columns include processor types (RS110, TS10, SS10, RS220, RS210) and RAID configurations. Rows list supported OS versions like Windows Server 2003, Windows Server 2008, and VMware ESXi.

1: インストールをサポートしない
B: サポートのみ
C: Windows Server 2008 R2 (Windows Server 2003 R2インストール代行サービス付)にて対応 / Windows Server 2003 R2インストールメディアが事前 (32bitのみ)
D: パンクモデル
E: Windows Server 2008 R2 (Windows Server 2008 32bitインストール代行サービス付)にて対応 / Windows Server 2008 (32bit/64bit)インストールメディアが事前
F: Linuxサポートサービス契約を前段に代行インストールに対応
G: Linuxサポートサービス契約を前段にサポート、代行インストールに対応せず
H: VMwareサポートサービス契約を前段にサポート、代行インストールに対応しない
I: VMwareサポートサービス契約を前段にサポート、代行インストールに対応、(VMware vSphere ESXi 5.0のダウングレード機能使用)
-: 未サポート
*1: 1.5GB以上のメインメモリーが16GBまでの構成をサポートします。また、コア数以上のコアまでの構成をサポートします。(ハイブリッドステータス/クラッシュ/ログ機能有効の場合を含む)。これらの条件を越える構成ではAMD/Intel製品をご使用下さい。
*2: 64bit版のみサポート
*3: VMwareをインストールする場合は、CPUの低下に必ずメモリアイ1式とメモリを裏渡し、各メモリアイは同構成でのメモリ容量が必要となります。
*4: 筐体プロセッサに対応してソフトインストールまたはアップグレードはLinuxサポートサービスを選択して下さい。